

HISTORICAL COPY

Form K6116


Supersedes K5804

DO NOT REMOVE

# ILLUSTRATED LIST OF PARTS


FOR

Nos 45K21, 45K25, 45K63  
and 45K78 Machines




No. 45K21 Machine

\*\*A Trade Mark of THE SINGER MANUFACTURING COMPANY




No. 45K25 Machine




No. 45K63 Machine

85529




85526




85530


85527



85528



85824




85822

85823

85828


85752



85749

85750


85753




85827








85825



85826













82528
















91329




91422




91672




91673




82414



91661




91168







91033



86135









86611

120342





98622

98623



98619

98620



91042

91043







95095



95094

95093



233 SS377

















91021 82426




91006




94869




82402




8908




91620



98608



82502



82503



94872



98627



98614



98642



187



239



213



904



SS517



SS574



82216



95489



ILLUSTRATED LIST OF PARTS

FOR

Nos. 45K21, 45K25, 45K63  
and 45K78 Machines

# CONTENTS

	Pages
Parts Complete for No. 45K21 Machine	43
Parts Special to 45K25 Machine	48
"    "    " 45K63    "	49
"    "    " 45K78    "	51
Accessories	53
Attachments	53
Bobbin Winders	55
Foot Lifter	56
Hot Wax Fittings	57
Driving Attachment	59
Numerical List of Parts	61



## INSTRUCTIONS FOR ORDERING

In ordering from this List, the prefix and affix letters with the part number **MUST BE** quoted exactly as they are shown in the first column.

A number always indicates the same part in whatever List it may appear, or for whatever machine.

The affix letters (where shown) indicate the style of finish, as follows:—

- A. Hardened, Polished, Nickel Plated and Buffed.
- A.A. Buffed and Chromium Plated.
- A.B. Hardened, Polished, Buffed and Chromium Plated.
- A.C. Brown Baking Enamel Finish.
- A.D. Grey Baking Enamel Finish.
- A.E. Hardened, Bright Rumbled and Nickel Plated.
- A.F. Hardened, Bright Rumbled and Nickel Plated, Bright Rumbled and Chromium Plated.
- A.J. Polished, Nickel Plated and Chromium Plated.
- A.K. Hardened, Polished, Nickel Plated and Chromium Plated.
- A.L. Heat Treated for Toughness.
- A.L.D. Heat Treated for Toughness and Polished.
- A.L.X. Heat Treated for Toughness and Black Oxide.
- A.M. Beige Synthetic Enamel.
- A.N. Red Synthetic Enamel Finish.
- A.P. Blue Synthetic Enamel Finish.
- A.P.P. Grey Wrinkle Finish.
- A.R. Beige Wrinkle Finish.
- A.S. Black Moulded Phenolic.
- A.T. Beige Moulded Phenolic.
- A.U. Brown Moulded Phenolic.
- A.V. Black Synthetic Enamel.
- A.X. Grey Dipping Enamel.
- B. Polished, Nickel Plated and Buffed.
- C. Hardened only.
- C.R. Hardened and Phosforic Treated.
- D. Polished only.
- E. Soft, not Polished.
- F. Hardened and Polished.
- F.J. Hardened, Polished and Nickel Plated.
- G. Bright Rumbled and Nickel Plated.
- H. Blued.
- J. Nickel Plated only.
- K. Hardened and Nickel Plated.
- L. Brass Plated.
- M. Oxidized.
- N. Japanned, Duil.
- P. Japanned, Bright.
- P.P. Wrinkle Finish.
- R. Phosforic Treated.
- S. Cadmium Plated.
- T. Copper Plated.
- T.A. Hardened, Polished, Copper and Nickel Plated and Buffed.
- T.B. Copper and Nickel Plated and Polished.
- T.J. Copper and Nickel Plated only.
- T.K. Hardened, Copper and Nickel Plated.
- T.L. Copper and Brass Plated.
- T.M. Copper Plated and Oxidized.
- U. Zinc Plated.
- V. Silver Plated.
- W. Polished and Nickel Plated.
- X. Black Oxide for Iron and Steel.
- X.C. Hardened and Black Oxide for Iron and Steel.
- Y. Black Nickel Plated only.
- Z. Chromium Plated.
- Z.A. Hardened, Polished, Nickel Plated, Buffed and Chromium Plated.
- Z.B. Polished, Nickel Plated, Buffed and Chromium Plated.
- Z.C. Hardened and Chromium Plated.
- Z.D. Polished and Chromium Plated.
- Z.G. Bright Rumbled, Nickel Plated, Bright Rumbled and Chromium Plated.
- Z.J. Nickel and Chromium Plated.
- Z.T. Copper and Chromium Plated.

Parts marked with an asterisk (\*) are furnished only when the repairs are made at Factory.

## PARTS COMPLETE

FOR

## No. 45K21 MACHINE

Drop Feed, Cylinder Bed, Needle Bar Link, for Leather and Textiles.

No.	Plate								
*91571		Arm with 446c, 82499 and 82519	...	...	...	...	...	...	...
8582	1062	" Dowel Pin (2)	...	...	...	...	...	...	...
118c	1876	" Screw (3)	...	...	...	...	...	...	...
91615	1063	Arm Shaft	...	...	...	...	...	...	...
82199	869	" " Bushing (back)	...	...	...	...	...	...	...
82549	1062	" " " (front)	...	...	...	...	...	...	...
446c	1876	" " " Set Screw for 82199	...	...	...	...	...	...	...
82400	871	" " Oil Tube	...	...	...	...	...	...	...
144c	1876	" " Screw	...	...	...	...	...	...	...
82402	2560	Arm Side Cover	...	...	...	...	...	...	...
51221d	1876	" " " Thumb Screw	...	...	...	...	...	...	...
82403	871	" Spool Pin	...	...	...	...	...	...	...
*91157	---	Bed (Cylinder)	...	...	...	...	...	...	...
94801	1068	Crank Connecting Rod with 94802, 91872 and two 158c	...	...	...	...	...	...	...
*94802		" " " Cap	...	...	...	...	...	...	...
94872	2561	" " " Oil Pad	...	...	...	...	...	...	...
158c	1876	" " " Screw	...	...	...	...	...	...	...
98627	2561	" " " Hinge Stud	...	...	...	...	...	...	...
98614	2561	" " " Cottar Pin	...	...	...	...	...	...	...
1668c	1875	" " " " " Nut	...	...	...	...	...	...	...
91006	2560	Face Plate	...	...	...	...	...	...	...
SS45d	1875	" " Screw (to attach to machine)	...	...	...	...	...	...	...
91007	---	Face Plate, complete, Nos. SS50f, 233d, 116c, 82449, 82150, 82455, 82502, 82503, 82525, 82551 and 91006	...	...	...	...	...	...	...

No.	Plate						
3032	869	<b>Feed Cam</b> with 446c	...	...	...	...	...
446c	1876	" " Set Screw	...	...	...	...	...
52165	869	<b>Feed Connecting Link</b>	...	...	...	...	...
375c	1876	" " " Hinge Screw (2)	...	...	...	...	...
1518e	1875	" " " " " Nut (2)	...	...	...	...	...
91422	1066	<b>Feed Dog</b> (General Work, Cloth or Leather)	...	...	...	...	...
91160	1874	" " Carrier	...	...	...	...	...
704c	1876	" " Screw	...	...	...	...	...
91161	1068	<b>Feed Forked Connection</b>	...	...	...	...	...
375c	1876	" " " Hinge Screw	...	...	...	...	...
1518e	1875	" " " " " Nut	...	...	...	...	...
82414	1066	<b>Feed Regulator</b>	...	...	...	...	...
1128e	1876	" " Hinge Screw	...	...	...	...	...
SS115	1875	" " Thumb Screw	...	...	...	...	...
*91162	—	<b>Feed Rock Shaft</b>	...	...	...	...	...
91163	1068	" " " 91162 with 91165 and 91166	...	...	...	...	...
91565	—	" " " 91163 with 98674	...	...	...	...	...
91165	—	" " " Carrier Slide with 1259c	...	...	...	...	...
1259c	1876	" " " " " Set Screw	...	...	...	...	...
91166	—	" " " " " Steady Pin	...	...	...	...	...
98674	—	" " " Crank with 156f and SS517c	...	...	...	...	...
SS517c	2562	" " " " Clamping Screw	...	...	...	...	...
156f	1876	" " " " Position Screw	...	...	...	...	...
86135	1067	<b>Gulde</b> ...	...	...	...	...	...
91168	1067	" Plate (.153 thick)	...	...	...	...	...
180f	1876	" " Screw (2)	...	...	...	...	...
793d	1876	" Thumb Screw (2)	...	...	...	...	...
82404	1599	<b>Machine Pulley</b> (two-speeds) with two 431c	...	...	...	...	...
91002	—	" " ( " ) (heavy) with two 434c	...	...	...	...	...
434c	1870	" " Set Screw	...	...	...	...	...
<i>NOTE.—No. 82404 is sent with this machine unless otherwise specified on order.</i>							
91021	2560	<b>Needle Bar</b>	...	...	...	...	...
91022	871	" " Connection with two 158e	...	...	...	...	...
158e	1876	" " Clamping Screw	...	...	...	...	...
91023	869	" " Link	...	...	...	...	...
375c	1876	" " " Hinge Screw	...	...	...	...	...
1518e	1875	" " " " " Nut	...	...	...	...	...
82520	871	<b>Needle Clamp</b>	...	...	...	...	...
156f	1876	" " Screw	...	...	...	...	...
82521	871	" " Thread Guide	...	...	...	...	...
50406d	1876	" " " " Screw	...	...	...	...	...
82522	—	<b>Needle Clamp</b> 82520 with 156f, 50406d and 82521	...	...	...	...	...

No.	Plate						
98639	2001	<b>Oscillating Rock Shaft</b> with 98636, 98637, two each SS537c and 1698e	...	...	...	...	...
98642	2562	" " " Hinge Pin	...	...	...	...	...
1513j	1875	" " " " " Nut	...	...	...	...	...
SS531c	2001	" " " " " Screw Bearing	...	...	...	...	...
1513j	1875	" " " " " " " Nut	...	...	...	...	...
98636	2001	" " " Steel Plate (bottom)	...	...	...	...	...
98637	2001	" " " " " (top)	...	...	...	...	...
SS537c	2001	" " " " " Binding Screw	...	...	...	...	...
1698e	2001	" " " " " " " Lock Nut	...	...	...	...	...
98641	—	<b>Oscillating Rock Shaft</b> , complete, Nos. 1668c, 98611, 98627 and 98639	...	...	...	...	...
91171	1068	<b>Oscillating Shuttle Shaft</b>	...	...	...	...	...
91172	1871	" " " Crank with 453c and 1850	...	...	...	...	...
11663	871	" " " " Pin	...	...	...	...	...
1850	1875	" " " " Roller and Stud	...	...	...	...	...
453c	1876	" " " " Set Screw	...	...	...	...	...
82426	2560	<b>Presser Bar</b> (with squared end)	...	...	...	...	...
91568	871	" " Lifting Bracket Automatic Thread Controller	...	...	...	...	...
207f	1876	" " " " " " " Screw	...	...	...	...	...
82429	869	" " Lifter	...	...	...	...	...
SS186d	1875	" " " Hinge Screw	...	...	...	...	...
1518e	1875	" " " " " Nut	...	...	...	...	...
91567	871	" " Lifting Bracket with 446c	...	...	...	...	...
116c	1876	" " " " Set Screw	...	...	...	...	...
82510	869	" " " " Tension Release	...	...	...	...	...
190f	1876	" " " " " Binding Screw	...	...	...	...	...
91569	—	" " " " 91567 with 82510 and two 190f	...	...	...	...	...
SS316d	1875	" " Screw Bushing	...	...	...	...	...
82130	871	" " Spring	...	...	...	...	...
91033	1067	<b>Presser Foot</b> (cloth)	...	...	...	...	...
85827	175	" " (leather)	...	...	...	...	...
91031	871	" " ( " )	...	...	...	...	...
SS65f	1875	" " Screw	...	...	...	...	...
<i>NOTE. No. 91033 is sent with this Machine unless another Presser Foot is specified on order.</i>							
95093	1697	<b>Shuttle Bobbin</b>	...	...	...	...	...
95094	1697	" Cylinder	...	...	...	...	...
91042	1697	" " Hinge Pin	...	...	...	...	...
91043	1697	" " Latch Spring	...	...	...	...	...
SS574d	2562	" " " " Screw	...	...	...	...	...
98620	1697	" Frame	...	...	...	...	...
95095	1697	" Tension Spring	...	...	...	...	...
SS377f	1697	" " " Adjusting Screw	...	...	...	...	...

No.	Plate	
98623	1697	<b>Shuttle</b> (Cylinder) 2½" diam., complete, Nos. SS377f, SS574d, 91042, 91043, 95093 to 95095 and 98620

*NOTE.—No. 98623 can only be used with No. 98608 and not with old style Shuttle Drivers.*

98608	2561	<b>Shuttle Driver and Feed Raising Cam</b>
11663	871	" " Pin

*NOTE.—No. 98608 can only be used with No. 98623 and not with old style shuttles.*

91151	827	<b>Shuttle Race</b> (cast iron)
91315	1874	" " Cap Spring
SS218d	1875	" " " " Screw
91452	827	" " Cover
91130	1874	" " Ring
SS318d	1875	" " " " Position Screw Stud (2)

SS317e	1875	<b>Tension Screw Stud</b>
1560d	1875	" " " " Regulating Thumb Nut
446c	1876	" " " " Set Screw

82445	869	<b>Tension Spring</b>
82446	871	" Washer (felt)
82447	869	" " (steel)
82448	-	" Wheel
82502	2561	<b>Tension</b> , complete, Nos. SS317e, 1560d, 82445, 82448, two each 82446 and 82447

82551	1062	<b>Thread Controlling Lever</b>
82525	869	" " " Spring
82155	871	" " " Stop Pin

82450	869	<b>Thread Eyelet</b>
SS50f	1875	" " " Screw

82119	869	<b>Thread Guard</b>
233d	1876	" " " Screw

2102	1062	<b>Thread Retainer Disc</b>
*443e	1876	" " " Screw Stud
33892	-	" " " " 443e with 1560d
1560d	1875	" " " " Regulating Thumb Nut
2103	869	" " " Spring

82503	2561	<b>Thread Retainer</b> , complete, Nos. 2103, 33892 and two 2102
-------	------	--

No.	Plate	
91617	1062	<b>Thread Take-up Cam</b> with SS320c and SS370c
SS320c	1875	" " " " Set Screw
SS370c	1062	" " " " Timing Screw

82452	-	<b>Thread Take-up Lever</b>
82453	869	" " " 82452 with RR24 and 1519c
SS221	1875	" " " " Hinge Screw
RR21	1875	" " " " Roller and Screw Stud
1519c	1875	" " " " " " " " Nut

91329	1066	<b>Throat Plate</b>
180f	1876	" " " Screw (2)

91796	1063	<b>Oil Box</b>
82159	1063	" " " Cover
82160	1062	" " " " Hinge Pin
80106	1062	" " " " Tatch Spring
219f	1876	" " " " " " " " Screw
82162	1062	" " " " " " " " Washer
82163	-	" " " " Oil Pad (cloth)
SS50f	1875	" " " " " " " " Screw
82162	1062	" " " " " " " " Washer
SS395f	1062	" " " " " " " " Stud Screw
SS124	1062	" " " " " " " " Set Screw
91797	1063	<b>Oil Box</b> , complete, Nos. SS124, SS50f, 219f, 80106, 82159, 82160, 82163, 91796 and two 82162

91177	-	<b>Work Plate</b>
SS39d	1875	" " " " Screw

*NOTE. No. 91177 is only supplied when specified on order and at an extra charge.*

## No. 45K25 Machine

Drop Feed, Cylinder Bed, Needle Bar Link and Roller Presser  
for Leather Work.

This Machine is the same as No. 45K21 with the exception that No. 82435 is  
sent in place of Presser Feet.

No.	Plate	
RR25	1875	<b>Roller</b> ( $1\frac{1}{2}$ " diam. $\times$ $\frac{5}{16}$ " face) with 378c and 1520r ...
82432	2559	" <b>Arm</b> ...
82433	2559	" " <b>Bracket</b> ...
430al	1876	" " " <b>Adjusting Screw</b> ...
1520r	1875	" " " " <b>Nut</b> ...
SS329c	1875	" " " <b>Clamping Screw</b> ...
82434	2559	" " <b>Lock Spring</b> ...
SS50c	1875	" " " <b>Screw</b> ...
313c	1870	" " <b>Screw Centre</b> ...
1519c	1875	" " " <b>Nut</b> ...
378c	1870	" <b>Bearing Screw</b> ...
1520r	1875	" " " <b>Nut</b> ...
82435	2559	<b>Roller Presser</b> , complete, ( $1\frac{1}{2}$ " $\times$ $\frac{5}{16}$ ") Nos. RR25, SS50c, SS329c, 430al, 1520r, 82432 to 82434, two each 313c and 1519c ...

## No. 45K63 Machine

Drop Feed, Cylinder Bed, Roller Presser and Trimming  
Attachment.

This Machine is the same as 45K21 with the following exceptions:

No.	Plate	
*91693		<b>Arm</b> , with 446c, 82199 and 82519 ...
91651	2559	<b>Face Plate</b> ...
91655	-	<b>Face Plate</b> , complete, Nos. SS50f, 233d, 416c, 82449, 82450, 82455, 82502, 82503, 82525, 82551 and 91654 ...
SS411	1875	<b>Face Plate Screw</b> (3) (to attach to machine) ...
91656	880	<b>Feed Dog</b> ...
91657	880	<b>Knife</b> , $\frac{3}{32}$ " ...
91658	880	" $\frac{1}{8}$ " ...
91659	880	" $\frac{5}{16}$ " ...
91660	2559	" <b>Bar</b> ...
91661	1066	" " <b>Block</b> with 620c ...
91662	880	" " " <b>Engaging Plunger</b> ...
91663	880	" " " " <b>Bush</b> ...
91665	880	" " " " <b>Head</b> ...
620c	1876	" " " " <b>Position Screw</b> ...
91664	880	" " " " <b>Spring</b> ...
91666		" " " " 91662 with 91663 to 91665 ...
91667	880	" " <b>Draw-up Spring</b> ...
1111	1876	" " " <b>Screw</b> (2) ...
91668	880	" " <b>Handle</b> ...
1011	1876	" " " <b>Screw</b> ...
91669	880	" " <b>Holder</b> ...
91670	880	" " <b>Gland</b> ...
203c	1876	" " " <b>Screw</b> (2) ...
207f	1876	" " " <b>Screw</b> (2) ...
239f	2562	" " <b>Stop Screw</b> ...
91671	2559	<b>Needle Bar</b> ...
196al	1876	" " <b>Needle Clamping Screw</b> ...
91672	1066	<b>Needle Bar Connection</b> with two 158c ...
91673	1066	" " " <b>Link</b> (adjustable) with 1229c ...
1229c	1876	" " " <b>Clamping Screw</b> ...

No.	Plate								
RR60	1875	<b>Roller</b> (1½" diam. × ⅝" face) with 378c and 1520r	...	...	...	...	...	...	...
82432	2559	" Arm	...	...	...	...	...	...	...
91674	2559	" " Bracket	...	...	...	...	...	...	...
430al	1876	" " " Adjusting Screw	...	...	...	...	...	...	...
1520r	1875	" " " " Nut	...	...	...	...	...	...	...
SS329c	1875	" " " Clamping Screw	...	...	...	...	...	...	...
82434	2559	" " Lock Spring	...	...	...	...	...	...	...
SS50c	1875	" " " Screw	...	...	...	...	...	...	...
313c	1876	" " Screw Centre	...	...	...	...	...	...	...
1519c	1875	" " " Nut	...	...	...	...	...	...	...
378c	1876	" Bearing Screw	...	...	...	...	...	...	...
1520r	1875	" " " Nut	...	...	...	...	...	...	...
91675	2559	<b>Roller Presser</b> , complete (1½" × ⅝"), Nos. SS50c, RR60, SS329c, 430al, 1520r, 82432, 82434, 91671, two each 313c and 1519c	...	...	...	...	...	...	...
91620	2561	<b>Thread Take-up Cam</b> with SS320c and SS370c	...	...	...	...	...	...	...
91677	880	" " " Link Connection with 90519	...	...	...	...	...	...	...
3012	880	" " " " " " Pin	...	...	...	...	...	...	...
90519	...	" " " " " " Slide Block with	...	...	...	...	...	...	...
			125060						
*125060	-	" " " " " " " Stud	...	...	...	...	...	...	...
94868	-	<b>Thread Take-up Lever</b> with 9219	...	...	...	...	...	...	...
94869	2560	" " " 94868 with RR21 and 1519c	...	...	...	...	...	...	...
*9219	-	" " " Thread Eyelet Bushing	...	...	...	...	...	...	...
91678	880	<b>Throat Plate</b>	...	...	...	...	...	...	...
91681	880	" " Cutting Bar, ⅛"	...	...	...	...	...	...	...
91691	-	" " " ⅜"	...	...	...	...	...	...	...
91680	880	" " " 1"	...	...	...	...	...	...	...
91679	880	" " " ⅜"	...	...	...	...	...	...	...
91695	-	" " " 1"	...	...	...	...	...	...	...
2371	1876	" " " Screw	...	...	...	...	...	...	...
91682	880	" " Spring Slide	...	...	...	...	...	...	...
91683	880	" " " Spring	...	...	...	...	...	...	...
91684	880	" " " Stop	...	...	...	...	...	...	...
2371	1876	" " " Screw	...	...	...	...	...	...	...
91685		<b>Throat Plate</b> , complete, Nos. 91678, 91680, 91682 to 91684 and three 2371	...	...	...	...	...	...	...

NOTE. When ordering 91685 state distance of trimmed edge from seam.

NOTE. Nos. 91679, 91680 and 91681 are sent with this machine unless otherwise specified on order.

## No. 45K78 Machine

Drop Feed, Cylinder Bed, Hinged Presser Foot, Fitted with High Lift Trimming Knife on hinged bracket controlled by spring pressure. For Stitching and Trimming Shoulder Pads of Coats (Arm Scye Work).

This machine is the same as No. 45K21 with the following exceptions:

No.	Plate								
*91693		Arm with 446c, 82199 and 82509	...	...	...	...	...	...	...
*98614		Bed (cylinder)	...	...	...	...	...	...	...
98668	2385	Face Plate	...	...	...	...	...	...	...
98669		Face Plate with Tension Releaser, complete, Nos. SS501, 233d, 116c, 7071, 9801, 82449, 82450, 82455, 82502, 82503, 82525, 82551, 98668 and 98672	...	...	...	...	...	...	...
SS114	1875	Face Plate Screw (3) (to attach to machine)	...	...	...	...	...	...	...
98617	2387	Feed Dog (8 teeth to inch) for 98663	...	...	...	...	...	...	...
98618	2386	Knife, ⅞" (short point)	...	...	...	...	...	...	...
91660	2559	" Bar	...	...	...	...	...	...	...
91661	1066	" " Block with 620c	...	...	...	...	...	...	...
91662	880	" " " Engaging Plunger	...	...	...	...	...	...	...
91663	880	" " " " " Bush	...	...	...	...	...	...	...
91665	880	" " " " " Head	...	...	...	...	...	...	...
620c	1876	" " " " " Position Screw	...	...	...	...	...	...	...
91661	880	" " " " " Spring	...	...	...	...	...	...	...
91666	-	" " " " " 91662 with 91663 to 91665	...	...	...	...	...	...	...
91667	880	" " Draw up Spring	...	...	...	...	...	...	...
1144	1876	" " " " " Screw (2)	...	...	...	...	...	...	...
91668	880	" " Handle	...	...	...	...	...	...	...
4011	1876	" " " Screw	...	...	...	...	...	...	...
2391	2562	" " Stop Screw	...	...	...	...	...	...	...
98649	2386	Knife Holder (hinged)	...	...	...	...	...	...	...
98650	2386	" " Carrier with 904c	...	...	...	...	...	...	...
2071	1876	" " " (Screw (2)	...	...	...	...	...	...	...
91670	880	" " Gland	...	...	...	...	...	...	...
203c	1876	" " " Screw (2)	...	...	...	...	...	...	...
98651	2386	" " Hinge Stud	...	...	...	...	...	...	...
904c	2562	" " " " " Set Screw	...	...	...	...	...	...	...
98652	2386	" " Spring	...	...	...	...	...	...	...
190c	1876	" " " Regulating Screw	...	...	...	...	...	...	...
98653	2386	" " Stop Plate	...	...	...	...	...	...	...
187c	2562	" " " Screw	...	...	...	...	...	...	...
98654		Knife Holder, complete, Nos. 187c, 190c and 98649 to 98653	...	...	...	...	...	...	...

No.	Plate								
98655	2385	<b>Needle Bar</b>	...	...	...	...	...	...	...
196al	1876	" "	Needle Clamping Screw	...	...	...	...	...	...
91672	1066	<b>Needle Bar Connection</b>	with two 158c	...	...	...	...	...	...
91673	1066	" "	" Link (adjustable) with 1229c	...	...	...	...	...	...
1229c	1876	" "	" " Clamping Screw	...	...	...	...	...	...
8554	---	<b>Presser Foot Hinge Pin</b>	...	...	...	...	...	...	...
98656	---	" "	Plate	...	...	...	...	...	...
98657	---	" "	Shank	...	...	...	...	...	...
95489	2562	" "	Spring	...	...	...	...	...	...
98658	2387	<b>Presser Foot</b>	(hinged), complete, Nos. 8554, 95489, 98656 and 98657	...	...	...	...	...	...
98670	2386	<b>Tension Releaser</b>	...	...	...	...	...	...	...
SS606c	2386	" "	Actuating Screw Stud	...	...	...	...	...	...
1735j	2386	" "	" " " Nut	...	...	...	...	...	...
98671	2386	" "	Lever with 7183	...	...	...	...	...	...
50527c	2386	" "	" Hinge Screw	...	...	...	...	...	...
206d	2386	" "	Screw	...	...	...	...	...	...
9804	2386	" "	Spring	...	...	...	...	...	...
7483	2386	" "	" Hook	...	...	...	...	...	...
7071	2386	" "	" Washer	...	...	...	...	...	...
98672	---	<b>Tension Releaser</b>	complete, Nos. SS606c, 1735j, 50527c, 98670, 98671 and two 206d	...	...	...	...	...	...
91620	2561	<b>Thread Take-up Cam</b>	with SS320c and SS370c	...	...	...	...	...	...
98659	2387	" "	" Link Connection with 90519	...	...	...	...	...	...
3012	880	" "	" " " Pin	...	...	...	...	...	...
90519	---	" "	" " " Slide Block with 125060	...	...	...	...	...	...
*125060	---	" "	" " " " " Stud	...	...	...	...	...	...
94868	---	<b>Thread Take-up Lever</b>	with 9219	...	...	...	...	...	...
*9219	---	" "	" Thread Eyelet Bushing	...	...	...	...	...	...
94869	2560	" "	" 94868 with RK24 and 1519c	...	...	...	...	...	...
98660	2387	<b>Throat Plate</b>	(flat top)	...	...	...	...	...	...
98661	2387	" "	Cover Plate	...	...	...	...	...	...
213d	2562	" "	" " Screw (2)	...	...	...	...	...	...
98662	2387	" "	Cutting Bar, $\frac{5}{16}$ "	...	...	...	...	...	...
237f	1876	" "	" " Screw	...	...	...	...	...	...
98663	---	<b>Throat Plate</b>	complete, Nos. 98660, 98662 and two 237f	...	...	...	...	...	...

## Accessories

No.	Plate								
95093	1697	Bobbins (2)	...	...	...	...	...	...	...
51077	1876	Machine Bolt with 1524e, 3" x $\frac{1}{4}$ " (4)	...	...	...	...	...	...	...
6055	1874	" " Nut Washer (4)	...	...	...	...	...	...	...
---	---	Instruction Book	...	...	...	...	...	...	...
---	---	Needles (6)	...	...	...	...	...	...	...
120342	1600	Oiler	...	...	...	...	...	...	...
86611	1600	Screw Driver (large)	...	...	...	...	...	...	...
120378	---	" " (small)	...	...	...	...	...	...	...
8908	2561	Wrench for 1519 and 1520, for 45K25 and 45K63 Machines	...	...	...	...	...	...	...

## Attachments

### Attachments for Stitching Rings into Golf Bags for No. 45K21 Machine.

No.	Plate								
85526	172	Feed Dog	...	...	...	...	...	...	...
85527	172	Guide (straight)	...	...	...	...	...	...	...
85528	172	Presser Foot	...	...	...	...	...	...	...
86400	---	Throat Plate	...	...	...	...	...	...	...
86401	---	" " Raised Plate	...	...	...	...	...	...	...
190c	1876	" " " " Screw	...	...	...	...	...	...	...
85529	172	Throat Plate, complete, Nos. 86400, 86401 and two 190c	...	...	...	...	...	...	...
85530	172	Attachment, complete, Nos. 85526 to 85529	...	...	...	...	...	...	...

### Attachment for Sewing Bag Handles for No. 45K21 Machine.

No.	Plate								
85531	882	Feed Dog	...	...	...	...	...	...	...
85532	882	Presser Foot	...	...	...	...	...	...	...
85533	882	Throat Plate	...	...	...	...	...	...	...
85534	882	Attachment, complete, Nos. 85531 to 85533	...	...	...	...	...	...	...



## Attachment for Saddlery Work for No. 45K21 Machine.

No.	Plate							
85749	175	Base	...	...	...	...	...	...
85750	175	" Spring	...	...	...	...	...	...
85751	175	" " Regulator with SS310d	...	...	...	...	...	...
SS310d	1875	" " " Thumb Screw	...	...	...	...	...	...
207d	1876	" " Screw	...	...	...	...	...	...
85325	...	" " " Washer	...	...	...	...	...	...
85752	175	Binder only, complete, Nos. 207d, 85325 and 85749 to 85751	...	...	...	...	...	...
85822	175	Combination Guide	...	...	...	...	...	...
85823	175	" " Base	...	...	...	...	...	...
161d	1876	" " Screw	...	...	...	...	...	...
85514	—	" " " Washer	...	...	...	...	...	...
85824	175	Combination Guide, complete, Nos. 161d, 85514, 85822 and 85823	...	...	...	...	...	...
85825	175	Presser Foot (for Oval Traces)	...	...	...	...	...	...
85826	175	" " ( " Sewing Rounds)	...	...	...	...	...	...
85753	175	" " ( " Binding)	...	...	...	...	...	...
85827	175	" " ( " General Work)	...	...	...	...	...	...
85828	175	Saddlery Attachment, complete, Nos. 85752, 85753 and 85824 to 85827	...	...	...	...	...	...

## Binder for Leather for No. 45K21 Machine.

No.	Plate							
85749	175	Base	...	...	...	...	...	...
85750	175	" Spring	...	...	...	...	...	...
85751	175	" " Regulator with SS310d	...	...	...	...	...	...
SS310d	1875	" " " Thumb Screw	...	...	...	...	...	...
207d	1876	" " Screw	...	...	...	...	...	...
85325	—	" " " Washer	...	...	...	...	...	...
85752	175	Binder only, complete, Nos. 207d, 85325 and 85749 to 85751	...	...	...	...	...	...
85753	175	Presser Foot	...	...	...	...	...	...
85754	—	Binder, complete, Nos. 85752 and 85753	...	...	...	...	...	...

## Welting Attachment for Boots for No. 45K21 Machine.

No.	Plate							
91422	225	Feed Dog	...	...	...	...	...	...
86132	225	Presser Foot	...	...	...	...	...	...
86128	—	Reel Holder Bracket	...	...	...	...	...	...
86129	—	" " " Pin	...	...	...	...	...	...
86130	225	Reel Holder, complete, Nos. 86128 and 86129	...	...	...	...	...	...
91329	225	Throat Plate	...	...	...	...	...	...
86127	225	Welt Guide	...	...	...	...	...	...
86134	225	Weltling Attachment, complete, Nos. 86127, 86130, 86132, 91329 and 91422	...	...	...	...	...	...

## Bobbin Winders

## Bobbin Winder (Friction) for Nos. 45K21, 45K25, 45K63 and 45K78 Machines with Fast Pulley.

No.	Plate							
82527	838	Bracket	...	...	...	...	...	...
SS56d	1875	" Screw	...	...	...	...	...	...
82528	838	Frame	...	...	...	...	...	...
32d	...	" Hinge Screw	...	...	...	...	...	...
5960	...	Friction Wheel (leather)	...	...	...	...	...	...
5961	...	" " Washer	...	...	...	...	...	...
333r	1876	" " " Screw	...	...	...	...	...	...
91446	838	Spindle	...	...	...	...	...	...
5963	...	" Flange	...	...	...	...	...	...
91447	838	Frame, complete, Nos. 333r, 5960, 5961, 5963, 82528 and 91446	...	...	...	...	...	...
82537	838	Spring	...	...	...	...	...	...
161d	1876	" Screw	...	...	...	...	...	...
82538	838	" " Washer	...	...	...	...	...	...
91448	...	Bobbin Winder, complete, Nos. 32d, 161d, 82527, 82537, 82538 and 91447	...	...	...	...	...	...

## Bobbin Winder (Friction) for Nos. 45K21, 45K25, 45K63 and 45K78 Machines when fitted with Driving Attachment.

This Bobbin Winder is the same as 91448 with the following exceptions:

No.	Plate							
91476	838	Bracket	...	...	...	...	...	...
91477	...	Bobbin Winder, complete, Nos. 32d, 161d, 82537, 82538, 91447 and 91476	...	...	...	...	...	...

## Bobbin Winder (Swinging Automatic, Right Hand) for 95093

No.	Plate							
27540	1187	Base	...	...	...	...	...	...
—	...	" Screw (wood) 1" No. 7 R H	...	...	...	...	...	...
27302	1487	Frame	...	...	...	...	...	...
50356b	1487	" Hinge Screw	...	...	...	...	...	...
1620j	1487	" " " Nut	...	...	...	...	...	...
27303	1487	" Spring	...	...	...	...	...	...
27541	1187	Pulley	...	...	...	...	...	...
98673	1487	Spindle	...	...	...	...	...	...
27306	1488	Spool Pin	...	...	...	...	...	...
27307	1488	" Stand	...	...	...	...	...	...
†27308	—	" " 27307 with 418d, 1562j, 2106, 10141, 27306, two each 2455 and wood screws 1" No. 10	...	...	...	...	...	...

† As No. 27308 can be supplied either Plated or Japanned, it is necessary, when ordering, to state which is required.

No.	Plate						
95197	I487	Stop Latch	...	...	...	...	...
35d	I487	" " Hinge Screw	...	...	...	...	...
2455	I488	Tension Disc	...	...	...	...	...
I562j	I488	" Regulating Thumb Nut	...	...	...	...	...
418d	I488	" Screw Stud	...	...	...	...	...
10141	I488	" Spring	...	...	...	...	...
2106	I488	Thread Guide	...	...	...	...	...
95198	I488	Bobbin Winder, Nos. 35d, 1620j, 27302, 27303, 27540, 27541, 50356b, 95197, 98673 and two wood screws 1" No. 7 R.H.	...	...	...	...	...
95199	—	Bobbin Winder, complete, Nos. 27308 and 95198	...	...	...	...	...

## Foot Lifter

No.	Plate						
91716	1063	Arm Lever	...	...	...	...	...
694d	1876	" " Hinge Screw	...	...	...	...	...
91457	755	Foot Lever with 176c	...	...	...	...	...
91459	755	" " Bracket	...	...	...	...	...
17881	755	" " " Hinge Pin	...	...	...	...	...
—	—	" " " Screw (wood) 1" No. 12	...	...	...	...	...
91458	755	" " Extension	...	...	...	...	...
176c	1876	" " " Set Screw	...	...	...	...	...
98626	755	" " Spring	...	...	...	...	...
91454	—	Foot Lever only, complete, Nos. 17881, 91457 to 91459, 98626 and two wood screws 1" No. 12	...	...	...	...	...
17877	755	Foot Lever Pitman Rod (lower)	...	...	...	...	...
17878	755	" " " " (upper)	...	...	...	...	...
17879	755	" " " " Clamp with two 161d	...	...	...	...	...
161d	1876	" " " " " Screw	...	...	...	...	...
17880	755	Foot Lever Pitman Rod, complete, Nos. 17877 to 17879	...	...	...	...	...
91453	755	" " " Connecting Hook (7" long)	...	...	...	...	...
91455	—	Foot Lever, complete, Nos. 17880 and 91451	...	...	...	...	...
91456	—	Foot Lifter, complete, Nos. 694d, 91453, 91455 and 91716	...	...	...	...	...

## Hot Wax Fittings for Nos. 45K21 and 45K25 Machines

NOTE. — These Fittings may be used on the above Machines, but are only supplied when specified on order and are charged extra.

No.	Plate						
94996		Face Plate	...	...	...	...	...
SS45f	1875	" " Screw (top)	...	...	...	...	...
I58e	1876	" " " (bottom)	...	...	...	...	...
82450	869	" " Thread Eyelet	...	...	...	...	...
SS50f	1875	" " " " Screw	...	...	...	...	...
91781		" " " Guard	...	...	...	...	...
201d	1876	" " " " Screw	...	...	...	...	...
94997		" " " Guide Stud (lower)	...	...	...	...	...
RR67	1875	" " " " " ( " ) Roller	...	...	...	...	...
1247d	1876	" " " " " ( " ) " Screw	...	...	...	...	...
94998		" " " " " complete, Nos. RR67, 1247d and 94997	...	...	...	...	...
448e	1876	" " " " " Set Screw	...	...	...	...	...
91357		" " " " " Wheel	...	...	...	...	...
52c	1876	" " " " " Hinge Screw	...	...	...	...	...
SS429c	1875	" " " " " " " Reception Screw	...	...	...	...	...
						Stud	
91782		" " " " Retaining Spring	...	...	...	...	...
1323f	1876	" " " " " Adjusting Screw	...	...	...	...	...
91783		" " " " " Plate	...	...	...	...	...
91781		Face Plate Thread Retaining Spring Position Pin	...	...	...	...	...
91366		" " " " Tension Protecting Bracket with 91367	...	...	...	...	...
207d	1876	" " " " " " " Screw	...	...	...	...	...
91367		" " " " " " " Steady Pin	...	...	...	...	...
91999		Face Plate, complete, Nos. SS50f, 52c, 201d, 207d, SS429c, 448e, 1323f, 82450, 91357, 91366, 91781 to 91784, 94996 and 94998	...	...	...	...	...
94875		Face Plate Swing Cover	...	...	...	...	...
94876		" " " " " Hinge Block (steel)	...	...	...	...	...
94877		" " " " " " " Pin	...	...	...	...	...
SS65d	1875	" " " " " " " Screw	...	...	...	...	...
82216	2562	" " " " " " " Steady Pin	...	...	...	...	...
80106	1062	" " " " " Retaining Spring	...	...	...	...	...
219f	1876	" " " " " " " Screw	...	...	...	...	...
82462	1062	" " " " " " " Washer	...	...	...	...	...
94878		Face Plate Swing Cover, complete, Nos. SS65d, 219f, 80106, 82216, 82162 and 94875 to 94877	...	...	...	...	...

No.	Plate	
94949	—	<b>Face Plate and Swing Cover</b> , complete, Nos. 94878 and 94999
94880	—	<b>Hot Wax Pot</b> ... ..
94881	—	" " " Bobbin Trough with two 193f ... ..
193f	1876	" " " " " Binding Screw ... ..
89363	—	" " " Tension Disc ... ..
*637e	1876	" " " " " Screw Stud ... ..
33929	—	" " " " " 637e with 1560d ... ..
1560d	1875	" " " " " Thumb Nut ... ..
2103	869	" " " " " Spring ... ..
94882	—	" " " " " Thread Guide ... ..
704c	1876	" " " " " " " Screw ... ..
91529	—	" " " " " Thread Eyelet (rubber) ... ..
SS308c	1875	" " " " " " " Screw ... ..
82462	1062	" " " " " " " Washer ... ..
94883	—	" " " " " Guide Bracket ... ..
91357	—	" " " " " " " Wheel ... ..
52c	1876	" " " " " " " " " Screw ... ..
94884	—	" " " " " " " " " complete, Nos. 94883, three each 52c and 91357
793d	1876	" " " " " " " " " Binding Thumb Screw ... ..
94885	—	" " " " " " " " " Releasing Lever ... ..
90e	1876	" " " " " " " " " Hinge Screw ... ..
86196	—	" " " " " " " " " Threading Hook for 94886 ... ..
94886	—	<b>Hot Wax Pot</b> , complete, Nos. 90e, SS308c, 704c, 2103, 33929, 82462, 86196, 91529, 94880 to 94882, 94884, 94885, two each 793d and 89363 ... ..
SS39d	1875	<b>Hot Wax Pot Binding Screw</b> ... ..
94992	—	<b>Heating Tube</b> ... ..
91363	—	" " " Connecting Bracket (for Arm front) ... ..
91363	—	" " " " " ( " " back) ... ..
91362	—	" " " " " ( " " Bed) ... ..
180f	1876	" " " " " " " " " Screw ... ..
91533h	—	" " " " " Lower Flame Guard Plate ... ..
180f	1876	" " " " " " " " " Screw ... ..
94976	—	<b>Heating Tube</b> , 94992, with 91362, 91533h, two 91363 and six 180f
94948	—	<b>Hot Wax Fittings</b> , complete, Nos. SS39d, 94886, 94949 and 94976 ... ..

## Singer Driving Attachment

No.	Plate	
91473	1599	Balance Wheel with 434c, 451c, 91475 and four 402e ... ..
91474	1599	" " Friction Pulley (two-speeds) with 448c and 91294 ... ..
91294	1599	" " " " " Centre Bearing ... ..
91475	1599	" " " " " Ring (cardboard) ... ..
402e	1876	" " " " " " " Screw ... ..
448c	1876	" " " " " " " Set Screw ... ..
434c	1876	" " " " " Set Screw (long) ... ..
451c	1876	" " " " " " " (short) ... ..
91296	755	Starting Lever ... ..
91297	755	" " Bracket ... ..
91298	—	" " " " " Hinge Pin ... ..
—	—	" " " " " Screw (wood), 11" No. 15 ... ..
91299	755	Starting Lever, Nos. 91296 to 91298 and three wood screws 11" No. 15 ... ..
17877	755	Starting Lever Pitman Rod (lower) ... ..
17878	755	" " " " " (upper) ... ..
17879	755	" " " " " Clamp with two 161d ... ..
161d	1876	" " " " " " " Screw ... ..
17880	755	Starting Lever Pitman Rod, complete, Nos. 17877 to 17879 ... ..
91460	—	Starting Lever and Pitman, complete, Nos. 17880 and 91299 ... ..
84275	—	Shaft Pulley (sectional, grooved), 10" diam., with two 597c ... ..
597c	1876	" " " Clamping Screw ... ..
91301	1599	Lever with 7958 and 91306 ... ..
91302	1599	" " Bracket ... ..
SS38c	1875	" " " Screw ... ..
91303	1599	" " Centre Plug (wood) ... ..
427c	1876	" " " " " Adjusting Screw ... ..
1508e	1875	" " " " " " " Nut ... ..
91306	—	" " Friction Pad (leather) ... ..
693d	1876	" " Hinge Screw ... ..
NN28c	1875	" " " " " Nut ... ..
91307	1599	" " Spring ... ..
161d	1876	" " " Screw ... ..
7958	—	" " " " " Pin ... ..
91309	—	Lever, complete, Nos. NN28c, 161d, 427c, 693d, 1508e, 91301 to 91303, 91307 and two SS38c ... ..
91478	—	<b>Driving Attachment</b> , complete, Nos. 84275, 91309, 91460, 91473 and 91474 ... ..

## Numerical List of Parts

No.	Plate	
SS22f	1875	Thread Take-up Lever Hinge Screw ...
RR24	1875	Thread Take-up Lever Roller and Screw Stud for 82453 and 94869 ...
RR25	1875	Roller (1 1/2" dia. x 3/8" face) with 378c and 1520r for 82435 ...
NN28c	1875	Driving Attachment Lever Hinge Screw Nut for 91309 ...
32d		Bobbin Winder Frame Hinge Screw for 91448 and 91477 ...
35d	1487	Bobbin Winder Stop Latch Hinge Screw for 95198 ...
SS38c	1875	Driving Attachment Lever Bracket Screw for 91309 ...
SS39d	1875	Hot Wax Pot Binding Screw for 94948 ...
SS39d	1875	Work Plate Screw ...
SS42f	1062	Oil Box Stud Screw Set Screw for 91797 ...
SS44f	1875	Face Plate Screw (to attach to machine) for 45K63 and 45K78 Machines ...
SS45d	1875	Face Plate Screw (to attach to machine) for 45K21 and 45K25 Machines ...
SS45f	1875	Face Plate Screw (top) for 94999 ...
SS50c	1875	Roller Arm Lock Spring Screw for 82435 and 91675 ...
SS50f	1875	Thread Eyelet Screw for 91007, 91655, 94999 and 98669 ...
SS50f	1875	Oil Box Oil Pad Screw for 91797 ...
52c	1876	Face Plate Thread Guide Wheel Hinge Screw for 94999 ...
52c	1876	Hot Wax Pot Thread Guide Bracket Wheel Screw for 94884 ...
SS56d	1875	Bobbin Winder Bracket Screw for 91448 and 91477 ...
RR60	1875	Roller (1 1/2" dia. x 3/8" face) with 378c and 1520r for 91675 ...
SS65d	1875	Face Plate Swing Cover Hinge Block Screw for 94878 ...
SS65f	1875	Presser Foot Screw ...
RR67	1875	Face Plate Thread Guide Stud (lower) Roller for 94998 ...
90c	1876	Hot Wax Pot Thread Releasing Lever Hinge Screw for 94886 ...
111f	1876	Knife Bar Draw-up Spring Screw for 45K63 and 45K78 Machines ...
SS115d	1875	Feed Regulator Thumb Screw ...

No.	Plate	
118e	1876	Arm Screw ... ..
144c	1876	Arm Shaft Screw ... ..
156f	1876	Feed Rock Shaft Crank Position Screw for 98674 ... ..
156f	1876	Needle Clamp Screw for 82522 ... ..
158e	1876	Crank Connecting Rod Cap Screw for 91801
158e	1876	Face Plate Screw (bottom) for 94999 ... ..
158e	1876	Needle Bar Connection Clamping Screw for 91022 and 91672 ... ..
161d	1876	Saddlery Attachment Combination Guide Screw for 85824 ... ..
161d	1876	Bobbin Winder Spring Screw for 91418 and 91477 ... ..
161d	1876	Foot Lifter Foot Lever Pitman Rod Clamp Screw for 17879 ... ..
161d	1876	Driving Attachment Starting Lever Pitman Rod Clamp Screw for 17879 ... ..
161d	1876	Driving Attachment Lever Spring Screw for 91309 ... ..
176e	1876	Foot Lifter Foot Lever Extension Set Screw for 91457 ... ..
180f	1876	Guide Plate Screw for 45K21, 45K25 and 45K78 Machines ... ..
180f	1876	Heating Tube Connecting Bracket Screw for 94976 ... ..
180f	1876	Heating Tube Lower Flame Guard Plate Screw for 94976 ... ..
180f	1876	Throat Plate Screw ... ..
SS186d	1875	Presser Bar Lifter Hinge Screw ... ..
187e	2562	Knife Holder Stop Plate Screw for 98654 ... ..
190c	1876	Knife Holder Spring Regulating Screw for 98654 ... ..
190c	1876	Throat Plate Raised Plate Screw for 85529 ... ..
190f	1876	Presser Bar Lifting Bracket Tension Release Binding Screw for 91569 ... ..
193f	1876	Hot Wax Pot Bobbin Trough Binding Screw for 94881 ... ..
196a1	1876	Needle Bar Needle Clamping Screw for 45K63 and 45K78 Machines ... ..
201d	1876	Face Plate Thread Guard Screw for 94999 ... ..
203c	1876	Knife Bar Holder Gland Screw for 45K63 Machine ... ..
203c	1876	Knife Holder Gland Screw for 45K78 Machine
206d	2386	Tension Releaser Screw for 98672 ... ..
207d	1876	Binder Base Spring Screw for 85752 ... ..
207d	1876	Face Plate Thread Tension Protecting Bracket Screw for 94999 ... ..

No.	Plate	
207f	1876	Knife Bar Holder Screw for 45K63 Machine
207f	1876	Knife Holder Carrier Screw for 45K78 Machine
207f	1876	Presser Bar Lifting Bracket Automatic Thread Controller Screw ... ..
213d	2562	Throat Plate Cover Plate Screw for 45K78 Machine ... ..
SS218d	1875	Shuttle Race Cap Spring Screw ... ..
219f	1876	Face Plate Swing Cover Retaining Spring Screw for 91878 ... ..
219f	1876	Oil Box Cover Latch Spring Screw for 91797
233d	1876	Thread Guard Screw for 91007, 91655 and 98669 ... ..
237f	1876	Throat Plate Cutting Bar Screw for 91685 and 98663 ... ..
237f	1876	Throat Plate Spring Slide Spring Stop Screw for 91685 ... ..
239f	2562	Knife Bar Stop Screw for 45K63 and 45K78 Machines ... ..
SS308e	1875	Hot Wax Pot Thread Eyelet Screw for 94886
SS310d	1875	Binder Base Spring Regulator Thumb Screw for 85751 ... ..
313c	1876	Roller Arm Screw Centre for 82435 and 91675
SS316d	1875	Presser Bar Screw Bushing ... ..
SS317e	1875	Tension Screw Stud for 82502 ... ..
SS318d	1875	Shuttle Race Ring Position Screw Stud ... ..
SS320e	1875	Thread Take-up Cam Set Screw for 91617 and 91620 ... ..
SS329e	1875	Roller Arm Bracket Clamping Screw for 82435 and 91675 ... ..
333r	1876	Bobbin Winder Friction Wheel Washer Screw for 91447 ... ..
SS370e	1062	Thread Take up Cam Tuning Screw for 91617 and 91620 ... ..
375e	1876	Feed Connecting Link Hinge Screw
375e	1876	Feed Forked Connection Hinge Screw ... ..
375e	1876	Needle Bar Connection Link Hinge Screw ... ..
SS377f	1697	Shuttle Tension Spring Adjusting Screw for 98623 ... ..
378e	1876	Roller Bearing Screw for RR25 and RR60 ... ..
SS395f	1062	Oil Box Stud Screw ... ..
401f	1876	Knife Bar Handle Screw for 45K63 and 45K78 Machines ... ..
402e	1876	Driving Attachment Balance Wheel Friction Pulley Ring Screw for 91473 ... ..
*413e	1876	Thread Retainer Screw Stud for 33892 ... ..
418d	1488	Bobbin Winder Tension Screw Stud for 27308

No.	Plate	
427c	1876	Driving Attachment Lever Centre Plug Adjusting Screw for 91309
SS429c	1875	Face Plate Thread Guide Wheel Hinge Screw Reception Screw Stud for 94999
430al	1876	Roller Arm Bracket Adjusting Screw for 82435 and 91675
434c	1876	Driving Attachment Balance Wheel Set Screw (long) for 91473
434c	1876	Machine Pulley Set Screw for 82404 and 91002
446c	1876	Arm Shaft Bushing Set Screw for 82499 for 91671 and 91693
446c	1876	Feed Cam Set Screw for 3032
446c	1876	Presser Bar Lifting Bracket Set Screw for 91567
446c	1870	Tension Screw Stud Set Screw for 91007, 91655 and 98669
448c	1876	Driving Attachment Balance Wheel Friction Pulley Set Screw for 91474
448c	1876	Face Plate Thread Guide Stud Set Screw for 94999
451c	1876	Driving Attachment Balance Wheel Set Screw (short) for 91473
453c	1876	Oscillating Shuttle Shaft Crank Set Screw for 91172
SS517c	2502	Feed Rock Shaft Crank Clamping Screw for 98674
SS531c	2001	Oscillating Rock Shaft Hinge Pin Screw Bearing
SS537e	2001	Oscillating Rock Shaft Steel Plate Binding Screw for 98639
SS574d	2502	Shuttle Cylinder Latch Spring Screw for 98623
507c	1870	Driving Attachment Shaft Pulley Clamping Screw for 84275
SS606c	2386	Tension Releaser Actuating Screw Stud for 98672
620c	1876	Knife Bar Block Engaging Plunger Position Screw for 91661
*637e	1876	Hot Wax Pot Tension Screw Stud for 33929
693d	1876	Driving Attachment Lever Hinge Screw for 91309
694d	1876	Foot Lifter Arm Lever Hinge Screw for 91456
704c	1876	Feed Dog Screw
704c	1876	Hot Wax Pot Tension Thread Guide Screw for 94886

No.	Plate	
793d	1876	Guide Thumb Screw for 86135
793d	1876	Hot Wax Pot Thread Guide Bracket Binding Thumb Screw for 94886
904c	2562	Knife Holder Hinge Stud Set Screw for 98650
1128c	1876	Feed Regulator Hinge Screw
1229c	1876	Needle Bar Connection Link Clamping Screw for 91673
1247d	1876	Face Plate Thread Guide Stud (lower) Roller Screw for 91998
1259c	1876	Feed Rock Shaft Corner Slide Set Screw for 91165
1323f	1876	Face Plate Thread Retaining Spring Adjusting Screw for 94999
1508c	1875	Driving Attachment Lever Centre Plug Adjusting Screw Nut for 91309
1513j	1875	Oscillating Rock Shaft Hinge Pin Nut
1513j	1875	Oscillating Rock Shaft Hinge Pin Screw Bearing Nut
1518c	1875	Feed Connecting Link Hinge Screw Nut
1518c	1875	Feed Forked Connection Hinge Screw Nut
1518c	1875	Needle Bar Connection Link Hinge Screw Nut
1518c	1875	Presser Bar Lifter Hinge Screw Nut
1519c	1875	Thread Take-up Lever Roller and Screw Stud Nut for 82453 and 94869
1519c	1875	Roller Arm Screw Centre Nut for 82435 and 91675
1520r	1875	Roller Arm Bracket Adjusting Screw Nut for 82435 and 91675
1520r	1875	Roller Bearing Screw Nut for RR25 and RR60
1560d	1875	Hot Wax Pot Tension Screw Stud Thumb Nut for 33929
1560d	1875	Tension Screw Stud Regulating Thumb Nut for 82502
1560d	1875	Thread Retainer Screw Stud Regulating Thumb Nut for 33892
1562j	1488	Bobbin Winder Tension Regulating Thumb Nut for 27308
1620j	1487	Bobbin Winder Frame Hinge Screw Nut for 95198
1668c	1875	Crank Connecting Rod Hinge Stud Cotter Pin Nut for 98641
1698c	2001	Oscillating Rock Shaft Steel Plate Binding Screw Lock Nut for 98639
1735j	2386	Tension Releaser Actuating Screw Stud Nut for 98672
1850	1875	Oscillating Shuttle Shaft Crank Roller and Stud for 91172



No.	Plate	
2102	1062	Thread Retainer Disc for 82503 ...
2103	869	Hot Wax Pot Tension Spring for 91886 ...
2103	869	Thread Retainer Spring for 82503 ...
2106	1488	Bobbin Winder Thread Guide for 27308 ...
2455	1488	Bobbin Winder Tension Disc for 27308 ...
3012	880	Thread Take-up Cam Link Connection Pin for 45K63 and 45K78 Machines ...
3032	869	Feed Cam with 446c ...
5960	—	Bobbin Winder Friction Wheel (leather) for 91447 ...
5961	—	Bobbin Winder Friction Wheel Washer for 91447 ...
5963	—	Bobbin Winder Spindle Flange for 91417 ...
6055	1874	Machine Bolt Nut Washer (Accessories)
7071	2386	Tension Releaser Spring Washer for 98669 ...
7483	2386	Tension Releaser Spring Hook for 98671 ...
7958	—	Driving Attachment Lever Spring Screw Pin for 91301 ...
8554	—	Presser Foot Hinge Pin for 98658 ...
8582	1062	Arm Dowel Pin ...
8908	2561	Wrench for 1519 and 1520 for 45K25 and 45K63 Machines (Accessories)
*9219	—	Thread Take-up Lever Thread Eyelet Bushing for 94868 ...
9804	2386	Tension Releaser Spring for 98669 ...
10141	1488	Bobbin Winder Tension Spring for 27308 ...
11663	871	Oscillating Shuttle Shaft Crank Pin ...
11663	871	Shuttle Driver Pin ...
17877	755	Foot Lifter Foot Lever Pitman Rod (lower) for 17880 ...
17877	755	Driving Attachment Starting Lever Pitman Rod (lower) for 17880 ...
17878	755	Foot Lifter Foot Lever Pitman Rod (upper) for 17880 ...
17878	755	Driving Attachment Starting Lever Pitman Rod (upper) for 17880 ...
17879	755	Foot Lifter Foot Lever Pitman Rod Clamp with two 161d for 17880 ...
17879	755	Driving Attachment Starting Lever Pitman Rod Clamp with two 161d for 17880 ...
17880	755	Foot Lifter Foot Lever Pitman Rod, complete, Nos. 17877 to 17879 for 91455 ...

No.	Plate	
17880	755	Driving Attachment Starting Lever Pitman Rod, complete, Nos. 17877 to 17879 for 91160 ...
17881	755	Foot Lifter Foot Lever Bracket Hinge Pin for 91454 ...
27302	1487	Bobbin Winder Frame for 95198 ...
27303	1487	Bobbin Winder Frame Spring for 95198 ...
27306	1488	Bobbin Winder Spool Pin for 27308 ...
27307	1488	Bobbin Winder Spool Stand for 27308 ...
†27308		Bobbin Winder Spool Stand 27307 with 418d, 1562j, 2106, 10141, 27306, two each 2455 and wood screws 1" No. 10, for 95199 ...

† As No. 27308 can be supplied, either Plated or Japanned it is  
necessary, when ordering, to state which is required.

27510	1487	Bobbin Winder Base for 95198 ...
27541	1487	Bobbin Winder Pulley for 95198 ...
33892		Thread Retainer Screw Stud 413c with 1560d for 82503 ...
33929		Hot Wax Pot Tension Screw Stud 637c with 1560d, for 94886 ...
50356b	1487	Bobbin Winder Frame Hinge Screw for 95198
50106d	1876	Needle Clamp Thread Guide Screw for 82522
50527c	2386	Tension Releaser Lever Hinge Screw for 98672
51077	1876	Machine Bolt with 1521c (3" x 1/4") (Accessories)
51224d	1876	Arm Side Cover Thumb Screw ...
52165	869	Feed Connecting Link ...
80106	1062	Face Plate Swing Cover Retaining Spring for 91878 ...
80106	1062	Oil Box Cover Latch Spring for 91797 ...
82216	2562	Face Plate Swing Cover Hinge Block Steady Pin for 94878 ...
82400	871	Arm Shaft Oil Tube ...
82402	2560	Arm Side Cover ...
82403	871	Arm Spool Pin ...
82404	1599	Machine Pulley (two-speeds) with two 134c
82411	1066	Feed Regulator ...
82426	2560	Presser Bar (with squared end) ...
82429	869	Presser Bar Lifter ...
82430	871	Presser Bar Spring ...
82432	2559	Roller Arm for 82435 and 91675 ...
82433	2559	Roller Arm Bracket for 82435 ...
82434	2559	Roller Arm Lock Spring for 82435 and 91675

No.	Plate	
82435	2559	Roller Presser, complete (1½" x ¾"), Nos. RR25, SS50c, SS329c, 430a1, 1520r, 82132 to 82434, two each 313c and 1519c for 45K25 Machine ... ..
82445	869	Tension Spring for 82502 ... ..
82446	871	Tension Washer (felt) for 82502 ... ..
82447	869	Tension Washer (steel) for 82502 ... ..
82448	—	Tension Wheel for 82502 ... ..
82449	869	Thread Guard for 91007, 91655 and 98669 ... ..
82450	869	Thread Eyelet for 91007, 91655, 91999 and 98669 ... ..
82452	—	Thread Take-up Lever for 82153 ... ..
82453	869	Thread Take-up Lever 82152 with RR24 and 1519c for 45K21 and 45K25 Machines ... ..
82455	871	Thread Controlling Lever Stop Pin for 91007, 91655 and 98669 ... ..
82459	1063	Oil Box Cover for 91797 ... ..
82460	1062	Oil Box Cover Hinge Pin for 91797 ... ..
82462	1062	Face Plate Swing Cover Retaining Spring Screw Washer for 91878 ... ..
82462	1062	Hot Wax Pot Thread Eyelet Screw Washer for 91886 ... ..
82462	1062	Oil Box Cover Latch Spring Screw Washer for 91797 ... ..
82462	1062	Oil Box Oil Pad Screw Washer for 91797 ... ..
82463	—	Oil Box Oil Pad (cloth) for 91797 ... ..
82499	869	Arm Shaft Bushing (back) for 91571 and 91693 ... ..
82502	2561	Tension, complete, Nos. SS317c, 1560d, 82445, 82448, two each 82446 and 82447 for 91007, 91655 and 98669 ... ..
82503	2561	Thread Retainer, complete, Nos. 2103, 33892 and two 2102, for 91007, 91655 and 98669 ... ..
82510	869	Presser Bar Lifting Bracket Tension Release for 91569 ... ..
82520	871	Needle Clamp for 82522 ... ..
82521	871	Needle Clamp Thread Guide for 82522 ... ..
82522	—	Needle Clamp 82520 with 156f, 50406d and 82521 for 45K21 and 45K25 Machines ... ..
82525	869	Thread Controlling Lever Spring for 91007, 91655 and 98669 ... ..
82527	838	Bobbin Winder Bracket for 91448 ... ..
82528	838	Bobbin Winder Frame for 91447 ... ..
82537	838	Bobbin Winder Spring for 91448 and 91477 ... ..
82538	838	Bobbin Winder Spring Screw Washer for 91448 and 91477 ... ..

No.	Plate	
82549	1062	Arm Shaft Bushing (front) for 91571 and 91693 ... ..
82551	1062	Thread Controlling Lever for 91007, 91655 and 98669 ... ..
84275	—	Driving Attachment Shaft Pulley (sectional, grooved), 10" diam., with two 597c, for 91478 ... ..
85325	—	Binder Base Spring Screw Washer for 85752 ... ..
85514	—	Saddlery Attachment Combination Guide Screw Washer for 85824 ... ..
85526	172	Feed Dog for 85530 ... ..
85527	172	Guide (straight) for 85530 ... ..
85528	172	Presser Foot for 85530 ... ..
85529	172	Throat Plate, complete, Nos. 86100, 86101 and two 190c for 85530 ... ..
85530	172	Attachment for Stitching Rings into Golf Bags, complete, Nos. 85526 to 85529 for 45K21 Machine ... ..
85531	882	Feed Dog for 85531 ... ..
85532	882	Presser Foot for 85531 ... ..
85533	882	Throat Plate for 85531 ... ..
85534	882	Attachment for Sewing Bag Handles, complete, Nos. 85531 to 85533 for 45K21 Machine ... ..
85749	175	Binder Base for 85752 ... ..
85750	175	Binder Base Spring for 85752 ... ..
85751	175	Binder Base Spring Regulator with SS310d for 85752 ... ..
85752	175	Binder only, complete, Nos. 207d, 85325, and 85749 to 85751 for 85751 and 85828 ... ..
85753	175	Saddlery Attachment Presser Foot (for Binding) for 85828 ... ..
85753	175	Binder Presser Foot for 85751 ... ..
85751	—	Binder (for leather), complete, Nos. 85752 and 85753 for 45K21 Machine ... ..
85822	175	Saddlery Attachment Combination Guide for 85824 ... ..
85823	175	Saddlery Attachment Combination Guide Base for 85824 ... ..
85824	175	Saddlery Attachment Combination Guide, complete, Nos. 161d, 85511, 85822 and 85823 for 85828 ... ..
85825	175	Saddlery Attachment Presser Foot (for Oval Traces) for 85828 ... ..
85826	175	Saddlery Attachment Presser Foot (for Sewing Rounds) for 85828 ... ..
85827	175	Presser Foot (leather) for 45K21 Machine ... ..

No.	Plate	
85827	175	Saddlery Attachment Presser Foot (for General Work) for 85828 ...
85828	175	Saddlery Attachment, complete, Nos. 85752, 85753 and 85824 to 85827 for 45K21 Machine ...
86127	225	Welting Attachment Welt Guide for 86134 ...
86128	—	Welting Attachment Reel Holder Bracket for 86130 ...
86129	—	Welting Attachment Reel Holder Bracket Pin for 86130 ...
86130	225	Welting Attachment Reel Holder, complete, Nos. 86128 and 86129 for 86134 ...
86132	225	Welting Attachment Presser Foot for 86134
86134	225	Welting Attachment for Boots, complete, Nos. 86127, 86130, 86132, 91329 and 91422 for 45K21 Machine ...
86135	1067	Guide for 45K21, 45K25 and 45K78 Machines
86196	—	Hot Wax Pot Threading Hook for 94886 ...
<del>86400</del>	—	<del>Throat Plate for 85520 ...</del>
86401	—	Throat Plate Raised Plate for 85520 ...
86611	1600	Screw Driver (large) ... (Accessories)
89363	—	Hot Wax Pot Tension Disc for 94886 ...
90519	—	Thread Take-up Cam Link Connection Slide Block with 125060 for 91677 and 98659 ...
91002	—	Machine Pulley (two-speeds) (heavy) with two 434c ...
91006	2560	Face Plate for 91007 ...
91007	—	Face Plate, complete, Nos. SS50f, 233d, 446c, 82449, 82450, 82455, 82502, 82503, 82525, 82551 and 91006 for 45K21 and 45K25 Machines ...
91021	2560	Needle Bar for 45K21 and 45K25 Machines ...
91022	871	Needle Bar Connection with two 158e for 45K21 and 45K25 Machines ...
91023	860	Needle Bar Connection Link for 45K21 and 45K25 Machines ...
91033	1067	Presser Foot (cloth) for 45K21 Machine ...
91034	871	Presser Foot (leather) for 45K21 Machine ...
91042	1697	Shuttle Cylinder Hinge Pin for 98621 ...
91043	1697	Shuttle Cylinder Latch Spring for 98623 ...
*91157	—	Bed (Cylinder) for 45K21, 45K25 and 45K63 Machines ...
91160	1874	Feed Dog Carrier ...
91161	1068	Feed Forked Connection ...
*91162	—	Feed Rock Shaft for 91163 ...
91163	1068	Feed Rock Shaft 91162 with 91165 and 91166 for 91565 ...

No.	Plate	
91165	—	Feed Rock Shaft Carrier Slide with 1259c for 91163 ...
91166	—	Feed Rock Shaft Carrier Slide Steady Pin for 91163 ...
91168	1067	Guide Plate (.153 thick) for 45K21, 45K25 and 45K78 Machines ...
91171	1068	Oscillating Shuttle Shaft ...
91172	1874	Oscillating Shuttle Shaft Crank with 453c and 1850 ...
91177	—	Work Plate for 45K21 and 45K25 Machines
91294	1599	Driving Attachment Balance Wheel Friction Pulley Centre Bearing for 91474 ...
91296	755	Driving Attachment Starting Lever for 91299
91297	755	Driving Attachment Starting Lever Bracket for 91299 ...
91298	—	Driving Attachment Starting Lever Bracket Hinge Pin for 91299 ...
91299	755	Driving Attachment Starting Lever, Nos. 91296 to 91298 and three wood screws 1 1/4" No. 15, for 91460 ...
91301	1599	Driving Attachment Lever with 7958 and 91306 for 91309 ...
91302	1599	Driving Attachment Lever Bracket for 91309
91303	1599	Driving Attachment Lever Centre Plug (wood) for 91309 ...
91306	—	Driving Attachment Lever Friction Pad (leather) for 91301 ...
91307	1599	Driving Attachment Lever Spring for 91309
91309	—	Driving Attachment Lever, complete, Nos. NN28c, 161d, 427c, 693d, 1508c, 91301 to 91303, 91307 and two SS38c for 91178 ...
91315	1874	Shuttle Race Cap Spring ...
91329	1066	Throat Plate for 45K21 and 45K25 Machines
91329	225	Welting Attachment Throat Plate for 86134
91357	—	Face Plate Thread Guide Wheel for 94999 ...
91357	—	Hot Wax Pot Thread Guide Bracket Wheel for 94884 ...
91362	—	Heating Tube Connecting Bracket (for Bed) for 94976 ...
91363	—	Heating Tube Connecting Bracket (for Arm, front) for 94976 ...
91363	—	Heating Tube Connecting Bracket (for Arm, back) for 94976 ...
91366	—	Face Plate Thread Tension Protecting Bracket with 91367 for 94999 ...
91367	—	Face Plate Thread Tension Protecting Bracket Steady Pin for 91366 ...

No.	Plate	
91422	1060	Feed Dog (General Work, Cloth or Leather) for 91329 for 45K21 and 45K25 Machines
91422	225	Welting Attachment Feed Dog for 86134 ...
91430	1874	Shuttle Race Ring ...
91446	838	Bobbin Winder Spindle for 91417 ...
91447	838	Bobbin Winder Frame, complete, Nos. 333r, 5960, 5961, 5963, 82528 and 91446 for 91448 and 91477 ...
91448	—	Bobbin Winder (friction), complete, for Nos. 45K21, 45K25, 45K63 and 45K78 Machines (with Fast Pulley), Nos. 32d, 161d, 82527, 82537, 82538 and 91447 ...
91451	827	Shuttle Race (cast iron) ...
91452	827	Shuttle Race Cover ...
91453	755	Foot Lifter Foot Lever Pitman Connecting Hook (7" long) for 91456 ...
91454	—	Foot Lifter Foot Lever only, complete, Nos. 17881, 91457 to 91459, 98626 and two wood screws 1" No. 12, for 91455 ...
91455	—	Foot Lifter Foot Lever, complete, Nos. 17880 and 91454 for 91456 ...
91456	—	Foot Lifter, complete, Nos. 694d, 91453, 91455 and 91716 ...
91457	755	Foot Lifter Foot Lever with 176c for 91454 ...
91458	755	Foot Lifter Foot Lever Extension for 91454 ...
91459	755	Foot Lifter Foot Lever Bracket for 91454 ...
91460	—	Driving Attachment Starting Lever and Pitman, complete, Nos. 17880 and 91299 for 91478 ...
91473	1599	Driving Attachment Balance Wheel with 434c, 451c, 91475 and four 402c for 91478 ...
91474	1599	Driving Attachment Balance Wheel Friction Pulley (two-speeds) with 418c and 91291 for 91478 ...
91475	1599	Driving Attachment Balance Wheel Friction Pulley Ring (cardboard) for 91473 ...
91476	838	Bobbin Winder Bracket for 91477 ...
91477	—	Bobbin Winder (friction), complete, for Nos. 45K21, 45K25, 45K63 and 45K78 Machines (when fitted with Driving Attachment), Nos. 32d, 161d, 82537, 82538, 91447 and 91476 ...
91478	—	Driving Attachment, complete, Nos. 84275, 91309, 91460, 91473 and 91474 ...
91529	—	Hot Wax Pot Thread Eyelet (rubber) for 94886 ...

No.	Plate	
91533h		Heating Tube Lower Flame Guard Plate for 94976 ...
91565		Feed Rock Shaft 91163 with 98674 ...
91567	871	Presser Bar Lifting Bracket with 446c for 91569 ...
91568	871	Presser Bar Lifting Bracket Automatic Thread Controller ...
91569		Presser Bar Lifting Bracket 91567 with 82510 and two 190f ...
*91571	—	Arm with 446c, 82499 and 82549, for 45K21 and 45K25 Machines ...
91615	1063	Arm Shaft ...
91617	1062	Thread Take-up Cam with SS320c and SS370c for 45K21 and 45K25 Machines ...
91620	2561	Thread Take-up Cam with SS320c and SS370c for 45K63 and 45K78 Machines ...
91654	2559	Face Plate for 91655 ...
91655		Face Plate, complete, Nos. SS501, 233d, 446c, 82449, 82450, 82455, 82502, 82503, 82525, 82551 and 91654 for 45K63 Machine ...
91656	880	Feed Dog for 45K63 Machine ...
91657	880	Knife, $\frac{5}{16}$ " for 45K63 Machine ...
91658	880	Knife, $\frac{1}{8}$ " for 45K63 Machine ...
91659	880	Knife, $\frac{5}{16}$ " for 45K63 Machine ...
91660	2559	Knife Bar for 45K63 and 45K78 Machines ...
91661	1066	Knife Bar Block with 620c for 45K63 and 45K78 Machines ...
91662	880	Knife Bar Block Engaging Plunger for 91666 ...
91663	880	Knife Bar Block Engaging Plunger Bush for 91666 ...
91664	880	Knife Bar Block Engaging Plunger Spring for 91666 ...
91665	880	Knife Bar Block Engaging Plunger Head for 91666 ...
91666		Knife Bar Block Engaging Plunger 91662 with 91663 to 91665 for 45K63 and 45K78 Machines ...
91667	880	Knife Bar Draw-up Spring for 45K63 and 45K78 Machines ...
91668	880	Knife Bar Handle for 45K63 and 45K78 Machines ...
91669	880	Knife Bar Holder for 45K63 Machine ...
91670	880	Knife Bar Holder Gland for 45K63 Machine ...
91670	880	Knife Bar Holder Gland for 45K78 Machine ...
91671	2559	Needle Bar for 45K63 Machine ...
91672	1066	Needle Bar Connection with two 158c for 45K63 and 45K78 Machines ...

No.	Plate	
91673	1066	Needle Bar Connection Link (adjustable) with 1229c for 45K63 and 45K78 Machines
91674	2559	Roller Arm Bracket for 91675
91675	2559	Roller Presser, complete, (1 1/2" x 3/8"), Nos. SS50c, RR60, SS329c, 430a1, 4520c, 82432, 82434, 91674, two each 313c and 4519c for 45K63 Machine
91677	880	Thread Take-up Cam Link Connection with 90519 for 45K63 Machine
91678	880	Throat Plate for 91685
91679	880	Throat Plate Cutting Bar, 3/8", for 91685
91680	880	Throat Plate Cutting Bar, 1/2", for 91685
91681	880	Throat Plate Cutting Bar, 3/8", for 91685
91682	880	Throat Plate Spring Slide for 91685
91683	880	Throat Plate Spring Slide Spring for 91685
91684	880	Throat Plate Spring Slide Spring Stop for 91685
91685		Throat Plate, complete, Nos. 91678, 91680, 91682 to 91684 and three 2371 for 45K63 Machine
		<i>NOTE.-- When ordering 91685 state distance of trimmed edge from seam.</i>
*91693		Arm with 446c, 82499 and 82519, for 45K63 and 45K78 Machines
91694		Throat Plate Cutting Bar, 3/8", for 91685
91695		Throat Plate Cutting Bar, 1/2", for 91685
91716	1063	Foot Lifter Arm Lever for 91156
91781		Face Plate Thread Guard for 94999
91782		Face Plate Thread Retaining Spring for 94999
91783		Face Plate Thread Retaining Spring Plate for 94999
91784		Face Plate Thread Retaining Spring Position Pin for 94999
91796	1063	Oil Box for 91797
91797	1063	Oil Box, complete, Nos. SS42f, SS50f, 219f, 80106, 82459, 82460, 82463, 91796 and two 82462 for 45K21, 45K25 and 45K63 Machines
94801	1068	Crank Connecting Rod with 91802, 94872 and two 158e
*94802		Crank Connecting Rod Cap for 94801
94868		Thread Take-up Lever with 9219 for 91869
94869	2560	Thread Take-up Lever 91868 with RR24 and 1519c for 45K63 and 45K78 Machines
94872	2561	Crank Connecting Rod Cap Oil Pad for 94801
94875		Face Plate Swing Cover for 94878

No.	Plate	
94876		Face Plate Swing Cover Hinge Block (steel) for 91878
94877		Face Plate Swing Cover Hinge Block Pin for 94878
94878		Face Plate Swing Cover, complete, Nos. SS65d, 219f, 80106, 82246, 82462 and 94875 to 94877 for 91919
94880		Hot Wax Pot for 94886
94881		Hot Wax Pot Bobbin Trough with two 1931 for 94886
94882		Hot Wax Pot Tension Thread Guide for 94886
94883		Hot Wax Pot Thread Guide Bracket for 94884
94884		Hot Wax Pot Thread Guide Bracket, complete, Nos. 94883, three each 52c and 91357 for 94886
94885		Hot Wax Pot Thread Releasing Lever for 94886
94886		Hot Wax Pot, complete, Nos. 90c, SS308c, 704c, 2403, 33929, 82462, 86196, 91529, 91880 to 91882, 91881, 91885, two each 793d and 89363 for 94948
94948		Hot Wax Fittings, complete, Nos. SS39d, 91886, 94949 and 94976, for 45K21 and 45K25 Machines
94949		Face Plate and Swing Cover, complete, Nos. 94878 and 94999, for 94948
94976		Heating Tube, 94992, with 94362, 91533b, two 91363 and six 180f, for 94948
94992		Heating Tube for 94976
94996		Face Plate for 94999
94997		Face Plate Thread Guide Stud (lower) for 94998
94998		Face Plate Thread Guide Stud, complete, Nos. RR67, 1247d and 94997, for 94999
94999		Face Plate, complete, Nos. SS50f, 52c, 204d, 207d, SS429c, 148c, 1323f, 82450, 91357, 91366, 91781 to 91784, 94996 and 94998 for 94949
95093	1697	Shuttle Bobbin for 98623
95094	1697	Shuttle Cylinder for 98623
95095	1697	Shuttle Tension Spring for 98623
95197	1487	Bobbin Winder Stop Latch for 95198
95198	1488	Bobbin Winder, Nos. 35d, 1620j, 27302, 27303, 27510, 27514, 50356b, 95197, 98673 and two wood screws 1" No. 7 R H for 95199

No.	Plate	
95199	—	Bobbin Winder (Swinging Automatic, Right Hand), complete, Nos. 27308 and 95198 for 95093 ... ..
95489	2562	Presser Foot Spring for 98658 ... ..
98608	2561	Shuttle Driver and Feed Raising Cam ... ..
98614	2561	Crank Connecting Rod Hinge Stud Cotter Pin for 98641 ... ..
98620	1697	Shuttle Frame for 98623 ... ..
98623	1697	Shuttle (Cylinder), 2 $\frac{1}{2}$ " diam., complete, Nos. SS377f, SS574d, 91042, 91043, 95093 to 95095 and 98620 ... ..
98626	755	Foot Lifter Foot Lever Spring for 91454 ... ..
98627	2561	Crank Connecting Rod Hinge Stud for 98641 ... ..
98636	2001	Oscillating Rock Shaft Steel Plate (bottom) for 98639 ... ..
98637	2001	Oscillating Rock Shaft Steel Plate (top) for 98639 ... ..
98639	2001	Oscillating Rock Shaft with 98636, 98637, two each SS537e and 1698c for 98641 ... ..
98641	—	Oscillating Rock Shaft, complete, Nos. 1668c, 98614, 98627 and 98639 ... ..
98642	2562	Oscillating Rock Shaft Hinge Pin ... ..
*98644	—	Bed (cylinder) for 45K78 Machine ... ..
98647	2387	Feed Dog (8 teeth to inch) for 98663 ... ..
98648	2386	Knife $\frac{7}{8}$ " (short point) for 45K78 Machine ... ..
98649	2386	Knife Holder (hinged) for 98654 ... ..
98650	2386	Knife Holder Carrier with 904c, for 98651 ... ..
98651	2386	Knife Holder Hinge Stud for 98654 ... ..
98652	2386	Knife Holder Spring for 98654 ... ..
98653	2386	Knife Holder Stop Plate for 98654 ... ..
98654	—	Knife Holder, complete, Nos. 187c, 190c and 98649 to 98653, for 45K78 Machine ... ..
98655	2385	Needle Bar for 45K78 Machine ... ..
98656	—	Presser Foot Plate for 98658 ... ..
98657	—	Presser Foot Shank for 98658 ... ..
98658	2387	Presser Foot (hinged), complete, Nos. 8554, 95489, 98656 and 98657, for 45K78 Machine ... ..
98659	2387	Thread Take-up Cam Link Connection with 90519, for 45K78 Machine ... ..
98660	2387	Throat Plate (flat top) for 98663 ... ..
98661	2387	Throat Plate Cover Plate for 45K78 Machine ... ..
98662	2387	Throat Plate Cutting Bar $\frac{5}{16}$ ", for 98663 ... ..
98663	—	Throat Plate, complete, Nos. 98660, 98662 and two 237f, for 45K78 Machine ... ..
98668	2385	Face Plate for 98669 ... ..

No.	Plate	
98669	—	Face Plate with Tension Releaser, complete, Nos. SS50f, 233d, 146c, 7071, 9801, 82149, 82150, 82455, 82502, 82503, 82525, 82551, 98668 and 98672, for 45K78 Machine ... ..
98670	2386	Tension Releaser for 98672 ... ..
98671	2386	Tension Releaser Lever with 7483, for 98672 ... ..
98672	—	Tension Releaser, complete, Nos. SS606c, 1735j, 50527c, 98670, 98671 and two 206d, for 98669 ... ..
98673	1487	Bobbin Winder Spindle for 95198 ... ..
98674	—	Feed Rock Shaft Crank with 156f and SS517c, for 91565 ... ..

No.	Plat.		
120342	1600	Order	(Accessories)
120378		Screw Driver (small)	(Accessories)
*125060		Thread Take up Cam Link Connection Slide Block Stud for 90519	